

CIRANOVA[®]
SINCE 1929

מפרט נתונים טכניים

מסיר ומנקה ריהוט גן DEGREYER

תיאור מוצר

מסיר ומנקה את הצבע האפור מעץ חיצוני ומחזיר את צבעו הטבעי.

הכנה

לתוצאה מירבית של המוצר יש להרטיב את העץ לפני השימוש

טיפים לפני שימוש:

יש למרוח את DEGREYER בעזרת מברשת צבע. תן לצבע להגיב במשך 10-15 דקות. אם יש צורך ניתן להספיג את החומר בעזרת מברשת בעלת שיער עבה לקבלת תוצאה טובה יותר. שוטפים היטב במים. במידת הצורך ניתן לחזור על הפעלה.

זמן ייבוש:

48 עד 72 שעות

כושר כיסוי:

5 to 8 m²/l /coat.



2,5L



לתחזוקה:

לאחר שטיפה וייבוש, ניתן לצבוע ולצפות בכל מוצר לריהוט חוץ (מלבד לכה) ובפרט מומלץ להשתמש :
Ciranova® WOODPROTECTOR



מידע נוסף:

בעת השימוש מומלץ ללבוש בגדי מגן.

הוראות זהירות:

מזיק במגע עם העור ובבליעה. יש להרחיק מהישג ידם של ילדים. לא לנשום את האדים. לבש בגדי מגן וכפפות מתאימים. אם נבלע, פנה מיד לייעוץ רפואי והראה את המיכל או התווית השתמש רק באזורים מאווררים היטב.

safeguard against an undesirable outcome. This technical data sheet is merely a guide and not a guarantee. All products are formulated to the best of our knowledge. The information is given as a result of many years experience. This product has had extensive tests carried out.

Produced by Debal Coatings nv

Industrieweg 29 - 8800 Beveren-Roeselare
Belgium
tel. +32 (0) 51 30 11 40 fax +32 (0) 51 31 26 48
ciranova@ciranova.be